



Refrigeration Note
Product Info

KVS Valves with CPC Systems




Introduction

Danfoss KVS valves have been tested with Emerson E2 controllers. This document explains the hookup and programming required. Please contact Danfoss technical support if you have any questions - 410-931-8716.


Wiring instructions

Danfoss KVS valves should be wired as shown. Contact Emerson regarding wire requirements and max distance.



Programming instructions

The E2 must be programmed for the step rate and max steps. Step rate should be 150 steps per second and max steps should be 3810.



Please refer to www.danfoss.us/foodretail for more information on the Danfoss KVS valve.

Danfoss, 7941 Corporate Drive, Baltimore, MD 21236 Tel. 410-931-8250, Fax 410-931-8256, www.danfoss.us/foodretail

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.